



PROFESSIONAL LAUNDRY INSTRUCTIONS FOR ANY GARMENT MADE USING NORFAB #366 or #371 FABRICS

Any personal protective garment made using the Norfab #366 fabric must be handled with care before and after laundry.

DO NOT: USE DETERGENT WITH BLEACH OR OXYCLEAN.

DO NOT: USE FABRIC SOFTENER OR DRYER SHEETS

DO NOT: LET YOUR GARMENT LAY CRUMPLED IN A HEAP ON THE FLOOR.

Before being laundered:

- When not being worn, hang up garment using a suit hanger in order to keep the stainless steel from kinking. If the garment is wadded or rolled up and stuck in a bin waiting for the launderer to pick up, the stainless steel, which has a memory, will most lightly have kinks that will be difficult to remove.
- Transport to and from launderer hung up on a suit hanger.

Laundry Guide

Dry Cleaning

- Perchloroethylene on regular cycle.
- Press by hand on a flat surface or by machine to smooth out the garment and minimize kinking.

Industrial Cleaning

- Wash separately from other garments.
- Machine wash 110°F (warm).
- Use Liquid Detergent.
- Do not use chlorine bleach, which can cause rapid degradation of aramid fibers.
- Use liquid detergent.
- Do not use soaps that contain animal fat.
- Remove from washer, and while still damp, hand press garment on a flat surface in order to smooth out the garment to minimize kinking.
- Hang to dry using suit hanger.
- Can be Tumbled Dry on Medium (140°F to 160°F). Shrinking up to 5% may occur as will kinking of the stainless steel.
- Do not over dry.
- Do not use fabric softener or dryer sheets. Fabric softener, starches and other laundry aides can coat the fibers and mask FR characteristics.
- Hang up garment using a suit hanger.

After being laundered

- Transport to and from launderer hung up on a suit hanger.
- When not in use, hang garment using a suit hanger.